

INNOVATIVE, SIMPLE DESIGN

The EasyLift is a modern lifting platform from Liftup. Walking-impaired and wheelchair users are now offered easy and stylish access between two levels

EQUAL OPPORTUNITIES

The EasyLift offers wheelchair users and the walking-impaired access to levels which would normally be hard to reach. Thanks to its lifting height of up to 125 cm, EasyLift can be used in many places – both indoors and outdoors. No more long waiting times, unsafe and insecure lifting appliances. EasyLift runs safely and comfortably as no other lift does.

STABLE AND COMFORTABLE

The EasyLift is the most stable and comfortable lifting platform on the market. With support in all four corners and fixing to the end wall, the user is conveyed safely and without difficulty to the desired level.

The four lifting motors are precisely controlled and completely synchronous, which guarantees safe and comfortable movement.

FLEXIBLE DESIGN

Clean, straight lines characterize the design, and its customized construction means that the EasyLift can be individually adjusted to its surroundings, thus providing an exclusive impression.

SAFETY ABOVE ALL

The EasyLift defines safety. A solid pressure plate beneath the entire platform safeguards people and objects from coming to harm. Naturally, the EasyLift is made according to all the current standards and thus meets all essential safety requirements. The EasyLift can be supplied with extra safety equipment such as safety barrier/door and key switch. The new wider model (1100) even with a special door lock.

BENEFITS

- A stable, registered lifting principle
- Anti-crushing protection
- Flexible design makes the EasyLift the perfect solution everywhere
- Minimum requirements for the installation site
- Battery backup in case of power failure
- Both indoor and outdoor use







CASES

Aalborg Airport

Aalborg Airport's 75th anniversary coincided with Liftup's installation No. 1000. The EasyLift in the staff canteen has an elegant look and in no way appears awkward. The lift has been fully integrated in the surroundings.



Madame Tussauds Amsterdam (NL)

There was a difference in the level of the floor itself and the television studio, which made the new exhibition area impossible to access for wheelchair users and those of limited mobility. The solution for the museum's level difference was Liftup's EasyLift – an elegant elevator that can be adapted to any building. With EasyLift, the new exhibition now offers access for all.



TECHNICAL SPECIFICATIONS

Platform size: 800 / 900 / 1100 x 1400 mm

Lifting capacity: 400 kg / 2 pers.

Lifting height: 70 - 1250 mm

Duty cycle: 2 min. operation every 5 min.

Lifting speed: 40 mm/sec.

Connection: 230 VAC (Charging)

Approval: CE marking 2006/42/EC (Machinery Directive)

Configure your own lift

Design your own lift and get the drawing in a mail in a few seconds

Liftup Product Configurator www.liftup.dk/lpc

